

The first time you start Light-O-Rama, shows will be disabled. This means that Light-O-Rama will not play any shows, even if they are currently scheduled to run. In order to enable shows, right-click on the Light-O-Rama icon in the system tray and select Enable Shows. To disable shows, right-click on the Light-O-Rama icon and select Disable Shows. If you want Light-O-Rama to always be ready to run scheduled shows with no intervention on your part, you should Enable Shows and set Launch at Startup.