

There are many keyboard shortcuts you can use within the Sequence Editor.

---

⌘

Key ⌘ ⌘ ⌘ ⌘ ⌘ Effect

⌘

<Shift>-A ⌘ ⌘ ⌘ ⌘ Turn on background effects mode for subsequent keystrokes

⌘

AA ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Turn on background effects mode for the next keystroke only

⌘

D⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Fade down

⌘

<Shift>-E⌘ ⌘ ⌘ Turn on regular effects mode for subsequent keystrokes

⌘

E⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Turn on regular effects mode for the next keystroke only

⌘

F⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Off

⌘

G⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Toggle (turns a cell on if it was off, and off otherwise)

⌘

I⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Set intensity

⌘

N⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ On

⌘

<Shift>-O⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Turn on foreground effects mode for subsequent keystrokes

⌘

O⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Turn on foreground effects mode for the next keystroke only

⌘

S⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Shimmer

⌘

T⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Twinkle

⌘

U⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Fade Up

⌘

<Enter>⌘ ⌘ ⌘ ⌘ ⌘ ⌘ Use the currently selected effect tool (from the Tools toolbar)

⌘

## Keyboard Shortcuts

Last Updated Tuesday, 26 August 2008 18:06

---

<Shift>-Del Â Â Â Copy Timings

<Shift>-Ins Â Â Â Paste Timings

CTRL-Z Â Â Â Â Â Undo

CTRL-Y Â Â Â Â Â Redo

Alt-Down Â Â Â Zoom in on Channels

Alt-Page Down Â Â Â MAX Zoom in on Channels

Alt-Up Â Â Â Â Â Zoom out on Channels

Alt-Page Up Â Â Â MAX Zoom out on Channels

CTRL-A Â Â Â Â Â Create new Animation Sequence

CTRL-M Â Â Â Â Â Create new musical Sequence

CTRL-S Â Â Â Â Â Save sequence

F5 Â Â Â Â Â Refresh Display

F1 Â Â Â Â Â Help

<Alt>-E Â Â Â Â Â The Edit Menu

<Alt>-F Â Â Â Â Â The File Menu

<Alt>-H Â Â Â Â Â The Help Menu

<Alt>-P Â Â Â Â Â The Play Menu

<Alt>-T Â Â Â Â Â The Tools Menu

<Alt>-V Â Â Â Â Â The View Menu

<Alt>-W Â Â Â Â Â The Window Menu