

When using the LOR software to control only non-LOR devices, the Hardware Utility will not allow you to access the X10 and Digital IO tabs. The workaround is to set the LOR device to an invalid or unused COM port. Then, you'll be able to access the other device tabs.